

TA-2	Overfill Alarm System
TA2-MON	Alarm Monitor Only
TA2-MON-RFB	Refurbished Alarm
TA2-SS	Sensor (J) Tube with 5-ft. Cable
TA-MAG	Magnets (each)
TA-2 SP	Overfill Alarm with Custom Size Pipe
TA-2 Speaker	Horn / Speaker – 123dB
	Cable (per foot)
TA-2 Clamps	Clamps
TA-2-033	Counterweight with Magnet
TA-2 20AE	Lower Housing with Sensor
TA-2 10P	10-Turn Potentiometer
TA-2 DC	Dry Contacts 2 amp, 120V AC/DC, N/O

TA2-OF	Gaugeless Tank Alarm (male connection, not suitable for mobile tanks)
TA2-OF-50	50-ft. Cable / 5-ft. Tube
TA2-OF-MON	Alarm Monitor Only
TA2-OF-SS	Sensor (J) Tube with 5-ft. Cable Standard 2" pipe is 18" long; longer pipe is _____ per ft.
RA-1	Remote Horn (plugs into a TA-2 box and cable goes to remote location) – 123 dB
MA-1	Master Alarm (for up to 10 tanks) Summation Device Cables attach from each alarm to MA-1 box; 110 required at MA-1 site. Flashing Strobe (option for MA-1)
TA-2 9V	Battery Connection Assembly

TA2-110	110 volt AC power option with battery back-up. Comes with 25 ft. of power cable. For use with all TA-2 alarms; not field retrofittable. This is a non-explosion proof transformer that must be mounted outside of the safety perimeter. 2" x 3" size.
---------	---